CABINET PARTS

For Models: ET18PKXFW01, ET18PKXFN01
(White) (Almond)

REFRIGERATOR



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: ET18PKXFW01, ET18PKXFN01
(White) (Almond)

Illus. No.	Part No.	DESCRIPTION
1		Cabinet (Not A Serviceable Part)
2	2157591	Hinge (Top)
3	2166108	Roller−Front (2)
4	489426	Screw
5	489385	Clamp, Tube (Water Supply Line)
6	2179826	Rivet
12	549193	Clamp−Cord
14	489459	Screw
15	489423	Screw
16	2183972	Hinge, Center
17	2183854	Shim, Hinge Center
18	489464	Screw
20	2189194	Hinge Butt
21	2174650	Screw
23	2172743	Shim, Bottom Hinge
24		Fitting, Water Tube (Not Serviced)
27		Hole Plug (6)
	2151652	White
	2151653	Almond
28		Seal, Front (Not Serviced)
30		Seal, Rear (Not Serviced)
31	2166251	Cover, Valve
35		Corner Filler (2)
	2163733	White
	2166187	Almond
36		Grille
	2189157	White
	2189158	Almond
38	487576	Washer
40		Cover−Hinge
	2160403	White
	2160404	Almond
41		Rail, Center (Not Serviced)
42		Corner Filler, Grille
	2166156	White
	2166204	Almond
44	2189059	Cover, Unit

DOOR PARTS

For Models: ET18PKXFW01, ET18PKXFN01
(White) (Almond)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Models: ET18PKXFW01, ET18PKXFN01
(White) (Almond)

Illus. No.	Part No.	DESCRIPTION
1		Refrigerator Door (Includes #9 & #21)
	2183898	White
	2183899	Almond
2		End Cap
	2183141	White
	2183142	Almond
4		End Cap, Handle (2)
	9791771	White
	9791772	Almond
5		Handle Center
	2148035	White
	2148036	Almond
6	489006	Screw
7	943188	Spacer
8	487909	Screw
9		Door Gasket, Magnetic
	2159057	Mist Beige
12		Cover, Screw
	9791769	White
	9791770	Almond
13		Nameplate
	2175383	White Model
	2175384	Almond Model
15	2159303	Shelf, Flip−Up
16	2180027	Trim, Door Shelf
17	489028	Screw
18	2195394	Door Bin (3)
19		Freezer Door Panel
	2182487	White
	2182491	Almond
20		Hole Plug
	2189000	White
	2189008	Almond
21	2183003	Thimble
23		Door Gasket, Magnetic
	2159327	Mist Beige
26	2189202	Bracket, Door Stop (2)
27	488921	Screw
		Page.
28		Hole Plug
	844478	White
	989196	Almond
29	2156007	Plug−Trim
30	2156006	Plug−Trim
31	2171036	Compartment Door
33		Handle, F.C.
	2171043	White
	2171044	Almond
37	2171282	Trim−Door (2)
38	943187	Shim
39		Handle End
	9791776	White
	9791777	Almond
41	2195916	Endcap (4)
42	2177260	Trim, Door
100	2182572	FeaturePak (Includes 10,15, 16,18,29,30,37, 41) Also See Shelf

LINER PARTS

For Models: ET18PKXFW01, ET18PKXFN01
(White) (Almond)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LINER PARTS

For Models: ET18PKXFW01, ET18PKXFN01
(White) (Almond)

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	531933	Grommet (2)
3	2166181	Gasket, Evaporator Cover (Side)
4	2193084	Timer, Defrost
6	941839	Hole Plug
7	2193493	Wire Assy. Control Box
8	2162085	Socket, Light (3)
9	2195603	Damper, Air
10	2183833	Fan Motor
11	2163777	Fan Blade
12	2179790	Control Box
13	2193304	Thermostat Assy. (Includes Items 5, 18 & 36)
14	489478	Screw
15	489412	Screw
16	2183154	Cover−Evaporator
17	527949	Light Bulb (2)
18	2163802	Weight, Thermal
19	1118894	Rocker Arm Switch
20	2171931	Valve
21	2176281	Cover, Air Diffuser
22	2193455	Knob, Thermostat
23	2182340	Air Tower
24	2176280	Air Diffuser, Bottom
25	2172565	Freezer Floor
26	2179877	Air Diffuser, Top
27	2190688	Cover, Hole
28	940014	Hole Plug
29	2163827	Bracket, Fan Motor
30	2166178	Gasket, Evaporator Cover (Top)
31	2174629	Air Return & Foil Assembly
32	487996	Cap
33	2195656	Wire Assembly Freezer Compt.
34	2176297	Knob, Damper
35	2179859	Post, Damper
36	2172532	Seal, Rear Thermostat
37	2163810	Bracket, Damper Knob
46	2176341	Clip, Defrost Timer

UNIT PARTS

For Models: ET18PKXFW01, ET18PKXFN01
(White) (Almond)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS

For Models: ET18PKXFW01, ET18PKXFN01
(White) (Almond)

Illus. No.	Part No.	DESCRIPTION
1	2195273	Plate, Unit Mounting
2	489478	Screw
3	2195400	Condenser
4	2176300	Heater, Defrost
5	2195391	Evaporator Assy.
6	489494	Screw
7	2172619	Drain Pan
8	2182380	Defrost Bi−Metal
9	2176301	Bracket, Heater
10	2163780	Extension, Air Baffle
11	2176302	Support Block
12	2162358	Cover
13		Overload
	2149959	Production (Includes Relay)
	2154759	Service (Includes Relay)
14		Grommet (4)
	2183042	Production
	1100826	Service
15		Relay (See Overload)
17	836054	Roller (2)
18	2179826	Rivet
19	2182338	Clip, Heater
20	489473	Screw, Compressor
28	2176660	Compressor (Includes Items 11, 12, 13, 15, 29, 32, 38 & 56) (Also Order 482801 Installation Kit & 876765 Tube Kit)
29	2174865	Drier
30	2155774	Clamp
32	2169137	Capacitor (Service Only)
38	2172890	Wire Assembly
39	2195677	Air Baffle
40	2183437	Motor, Condenser
42	2184584	Wire Assy. Unit
43	2190685	Fan Blade
44	486692	Nut
46	2179722	Tube, Discharge
47	2184550	Tube, Suction
48	2194319	Tube, Process
49	2174670	Tube, Condenser To Heat Loop
56	489373	Screw
58	2163795	Evap. Tray

Illus. No.	Part No.	DESCRIPTION

Following Parts Not Illustrated and Optional Parts Not Included

	978025	Valve, Access (1/4")
	978026	Valve, Access (5/16")
	978027	Valve, Access (3/8")
	978028	Valve, Access (1/2")
	978029	Valve, Access (5/8")
	978030	Valve, Access (3/4")
	876764	Valve, Access (3/16")
	482278	Start Kit

REFRIGERANT CHARGE

3.75 Ozs.
(R134A)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

SHELF PARTS

For Models: ET18PKXFW01, ET18PKXFN01
(White) (Almond)



Illus. No.	Part No.	DESCRIPTION
1	841180	Ice Tray (2)
2	2163859	Shelf
3	2195342	Cover, Crisper
4	2190601	Crisper Pan
5	2163826	Shelf, Ladder
6	2172541	Support, Crisper Cover
7	2163835	Track, Crisper
8	2176275	Shelf
9	2190599	Crisper Pan
10	2169921	Glass, Crisper Cover
11	2163756	Shelf, Ladder (2)
12	489415	Screw
13	2169933	Egg Bin
14	2195404	Meat Pan
18	2193314	Trim, Shelf Front
19	2193313	Trim, Shelf Rear
20	2169917	Glass, Half Shelf
21	2177824	Glass, Full Shelf
22	2163862	Shelf, Cantilever
23	2163762	Cup, Shelf Mtg.
24	2193394	Trim, Shelf Rear
25	2176305	Pan Shelf, Cantilever
26	520965	Screw Support
100	2182572	FeaturePak (Includes 13,14, 18,19,20) Also See Door Page.

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LITERATURE AND OPTIONAL PARTS

For Models: ET18PKXFW01, ET18PKXFN01
(White) (Almond)

Illus. No.	Part No.	DESCRIPTION

Parts Not Illustrated and Optional Parts (Not Included)

PARTS NOT ILLUSTRATED

	978941	Insulation, Fiberglass (63−1/2" x 35−1/2" x 2−5/8")
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4" x 108")
	876305	Kit, Insulation (14 Pcs. 3" x 24" x 48")
	876370	Kit, Insulation (2 Pcs. 3" x 24 " x 48")
	876029	Kit, Foam Slab (30" x 32−1/2" x 1−1/2")
	505587	Sealer, Mastic (1 Qt.)
	511873	Touch−Up, White Porcelain (2 Oz.)
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1−1/4 Oz.)
	606755	Bag, Insulation (36−5/8" x 46")
	799833	Kit, Evaporator Repair (Aluminum Epoxy)
	799832	Kit, Porcelain Repair (White)
	503695	Cork Sealer (1/4 Pound)
	2172516	Door Reversal Instructions

Illus. No.	Part No.	DESCRIPTION

Customer Touch−Up Material

	*350942	Primer, White (13 Oz. Spray Can)
	*350939	Enamel, Black (13 Oz. Spray Can)
	*350930	Enamel, White (13 Oz. Spray Can)
	*350956	Enamel, Almond (13 Oz. Spray Can)
	72017	Brush Touch−Up Kit (White)
	72032	Brush Touch−Up Kit (Black)
	72107	Brush Touch−Up Kit (Almond)

Refinishing Material

	799344	Enamel, White (1 Qt. Uncut)
	978883	Enamel, Almond (1 Qt. Uncut)
	833938	Kit, Terminal Connector

* not to be used where the paint may make contact with the door gaskets.

Illus. No.	Part No.	DESCRIPTION

LITERATURE PARTS

	LIT2195481	Service & Wiring Sheet
	LIT2195604	Energy Label
	LIT2195369	Use & Care Guide

Following May Be Purchased

DO−IT−YOURSELF REPAIR MANUALS

	LIT677969	Do−It−Yourself Manual Ref./Fzr.
	LIT677971	Do−It−Yourself Manual, Icemaker

ICE MAKER FIELD INSTALLABLE

		ECKMF94

TORX SCREW WRENCH

	1117510	Torx Key